



APPLY TWO STAINLESS STEEL
 TEK SCREW (#12 x 1 1/2")
 ON EACH CLAMP INTO THE
 SNOWSTOP AS SHOWN.

(2) PC. SEAM
 CLAMP, ONE
 ASSEMBLY PER
 SEAM.

(2) 3/8" S/S FASTENERS
 PER CLAMP

BEMO SNOW STOP SYSTEM
 LOCATE AS SHOWN ON
 THE PLANS.

PANEL:
 BEMO

DETAIL:
 SNOW RETENTION SYSTEM

REVISION:
 3

PAGE:
 1 OF 1