


NOTE:
A COUNTER FLASHING (NOT SHOWN) MUST BE INSTALLED TO WEATHERTIGHT THE TOP OF THE CURB. SEE DETAILS A - D.

NOTES:
DO NOT FASTEN CURB FLASHINGS TO ROOF CURB; CURB FLASHINGS TO MOVE WITH PANEL SYSTEM DURING THERMAL EXPANSION & CONTRACTION.

SHORT PANELS ABOVE & BELOW CURB ARE TO BE BOLTED TOGETHER AND TO FULL LENGTH PANELS ON EITHER SIDE SO AS TO MOVE AS A UNIT DURING THERMAL EXPANSION & CONTRACTION. USE $\frac{5}{16}$ " SS BOLT ASSEMBLIES WITH SS/NEOPRENE BONDED WASHERS (SEE SIDEPAN DETAILS A & B BELOW)



SEE ATTACHED EXPLODED VIEW OF CURB FLASHINGS FOR CONFIGURATION & LAYOUT. ALL JOINTS BETWEEN FLASHINGS ARE TO BE SEALED WATER TIGHT WITH 2 SDE BY SIDE ROWS OF $\frac{3}{32}$ " x $\frac{1}{2}$ " BUTYL SEALANT TAPE. FASTENERS ARE TO BE $\frac{1}{4}$ " DIA SELF SEALING BULB-TITE RIVETS SPACED 4" MAX. O.C.

NOTE:
A COMPLETELY WELDED CURB ASSEMBLY MAY BE REQUIRED FOR 20yr WARRANTY. CONSULT BEMO TECHNICAL DEPARTMENT

BEMO ROOF CURB DETAIL

BEMO·USA

Xtreme Roofing Solutions

P: 1.800.926.2366

TAMPA, FLORIDA • PHOENIX, ARIZONA • PITTSBURGH, PENNSYLVANIA

PANEL:

BEMO

DATE:

DETAIL:

ROOF CURB ASSEMBLY

PAGE:

1 OF 1